BRAC UNIVERSITY DEPARTMENT OF COMPUTER SCIENCE AND ENGINEERING COURSE NO.: CSE250

Circuits and Electronics Laboratory

Experiment No. 03

Name of the Experiment:

OBSERVATION OF APPLICATION OF A LOAD, AFFECTING THE TERMINAL VOLTAGE OF THE SUPPLY


OBJECTIVE:

The objective of this experiment is to observe the change in supply voltage according to changing load.

APPARATUS:

- 1) DC Power Supply
- 2) Resistor 330Ω (3), $5.6k\Omega$ (3), $10k\Omega$ (3), $18k\Omega$ (3)
- 3) Trainer Board
- 4) Digital Multimeter
- 5) Wires

FIGURE:



PROCEDURE:

- Set up the circuit in no load condition. Use 12volt from DC power supply.
- Measure the voltage across each of the series resistances & also measure the current through the closed path.
- Connect the load using $R=100\Omega$. Measure voltage V_1 , V_2 & V_3 & note them down in tabular form. Also measure the current I_1 , I_2 & I_3 through the three load branches & note them down.
- Replace the 100Ω load with $5.6k\Omega$, $10k\Omega$ & $18k\Omega$ resistance. Repeat step 3.

TABLE:

Load Resistance	V_1	V_2	V_3	$I_1 = V_1/R \text{ (mA)}$	$I_2 = V_2/R \text{ (mA)}$	$I_3 = V_3/R \text{ (mA)}$
No Load						
100Ω						
5.6kΩ						
10kΩ						
18kΩ						

REPORT:

- 1. Compare the different values of voltages obtained in different steps.
- 2. Compare the different values of current obtained in different steps.
- 3. What is the main observation in change in voltage or current, while changing load resistance?
- 4. Let us assume, for the figure given, the value of the series resistances are 220Ω each. Find out V_1, V_2, V_3 & I_1, I_2, I_3 for $R=80\Omega, 1k\Omega, 100k\Omega$.